

# FILSON

SINCE 1897

## INSTRUCTIONS

### SCREW-DOWN CROWNS

#### CROWN FUNCTIONALITY

The components of your Filson watch are made of the finest materials and have been rigorously inspected to meet our strict criteria. Some Filson watches feature a screw-down crown, which adds an extra level of water-tightness. To safeguard your investment, it is important to understand how this type of crown works:

- 1 To make the crown operational, unscrew it from the case by turning it counterclockwise until it releases. Once released, follow the instructions for setting the time/date as described in the next sections.
- 2 To reseal the crown, press it in against the case until the threads engage, and turn clockwise until tight.




### CHRONOGRAPH MODEL

#### DESCRIPTION OF THE DISPLAY AND CONTROL BUTTONS

Please note:


Before using the chronograph functions, please ensure that:

- The crown is in position I (= normal position).
- The two chronograph hands are precisely at zero position following activation of push-button B. If the hands are not precisely at zero, their positions must be adjusted. (See the chapter *Adjusting the Chronograph Hands to Zero.*)



#### SETTING THE TIME


- 1 Pull out the crown to position III. (The watch stops.)
- 2 Turn the crown until you reach the correct time.
- 3 Push the crown back to position I.



### SINGLE TIME MODEL

#### SETTING THE TIME

- 1 Pull out the crown to position II. (The watch stops.)
- 2 Turn the crown until you reach the correct time.
- 3 Push the crown back to position I.



#### SETTING THE DATE

- 1 Pull out the crown to position II. (The watch continues to run.)
- 2 Turn the crown until the correct date appears.
- 3 Push the crown back to position I.



#### ADJUSTING THE CHRONOGRAPH HANDS TO ZERO

- 1 Pull crown out to position III. (All two chronograph hands are in their correct or incorrect zero position.)
- 2 Keep push-buttons A and B depressed simultaneously for at least 2 seconds. (The center stop-second rotates by 360° - corrective mode is activated.)
- 3 Press push-button A to single step the center stop-second hand. Press and hold push-button A to advance the center stop-second hand quickly. 3b Press push-button B to advance to the next hand.
- 4 Press push-button A to single step the minute counter hand. Press and hold push-button A to advance the minute counter hand quickly.
- 5 Return the crown to position I.



#### BASIC FUNCTION (START / STOP / RESET)

Example


- 1 Start: press push-button A.
- 2 Stop: to stop the timing, press push-button A once more and read the two chronograph counters: 20min / 10sec.
- 3 Zero positioning: Press push-button B. (The two chronograph hands will be reset to their zero positions.)



#### ACCUMULATED TIMING

Example

- 1 Start: start timing.
- 2 Stop: e.g., 15 min. 5 sec. following 1.
- 3 Restart: timing is resumed.
- 4 \*Stop: e.g., 13 min. 5 sec. following 3. The accumulated time = 28 min. 10 sec.
- 5 Reset: the three chronograph hands are returned to their zero positions.



Please note: \*Following 4, the accumulation of the timing can be continued by pressing push-button A (Restart/Stop, Restart/Stop,...)

#### INTERMEDIATE OR INTERVAL TIMING

Example

- 1 Start: start timing.
- 2 Display interval: e.g., 10 min. 10 sec. following 1. Timing continues in the background.
- 3 Making up the measured time: The two chronograph hands are quickly advanced to the ongoing measured time.
- 4 Stop: e.g., 28 min. 10 sec. following 1.
- 5 Reset: the three chronograph hands are returned to their zero positions.



Please note: \*Following 3, further intervals or intermediates can be displayed by pressing B (display interval / make up measured time, ...)

### WATER RESISTANCE

All the Filson timepieces are designed with a minimum water-resistance rating of 10ATM (330ft / 100m).

The water-resistance of a timepiece protects the movement from dust, moisture, and risk of damage to the movement should it be immersed in water. Please see chart for guidelines for recommended exposure of various water ratings.

It is important not to attempt to adjust the position of the crown while the timepiece is in contact with water. Water can enter the case causing damage to the movement. For timepieces with screw-down crowns, it is important to ensure the crown is in the proper position and completely locked before contact with water. For timepieces with chronograph functions, do not engage the chronograph under water, as water may leak into the case and cause damage to the movement.

INDICATION		WATER-RELATED USE		
	Water-Resistance Characteristics	Light Spray, Perspiration, Light Rain, etc.	Swimming, etc.	Skin Diving (Diving without oxygen cylinder)
1	3 ATM	OK	NO	NO
2	5 ATM	OK	NO	NO
3	10 ATM	OK	OK	NO
4	20 ATM	OK	OK	OK
5	30 ATM	OK	OK	OK

ALWAYS SET THE CROWN IN THE NORMAL POSITION AND TIGHTEN SCREW LOCK CROWN COMPLETELY.

### CARE AND PRECAUTION

Each Filson timepiece is designed and manufactured to the highest of standards. Unlike most other mechanical objects, a watch operates non-stop. In order to ensure optimal performance and longevity from your Filson timepiece, please review the simple guidelines for care and precautions.

#### CARE

- Clean your watch with a soft cloth and water only. Do not submerge your watch under water unless it is water rated.
- After saltwater use, rinse watch under tap water and wipe dry with a soft cloth.
- Metal bracelets should be cleaned periodically. Clean with a soft brush dipped in mild soapy water and dry thoroughly with a soft cloth.
- We advise having your timepiece serviced every 18 – 24 months to ensure long use and trouble free operation.

#### PRECAUTIONS

Your timepiece is a complex integration of parts and components brought together by skilled craftsmen. There are certain actions or environmental situations that may damage or impede your timepiece's ability to perform optimally.

It is important to avoid the following conditions: extreme heat or cold, as well as prolonged periods of exposure to direct sunlight, exposure to wet conditions that exceed your timepiece's water rating. (See caseback and chart).

Your timepiece should not be affected by magnetic fields generated by household items such as televisions and stereos, but avoidance of other strong electric fields or static electricity, which may interrupt mechanism, is suggested. It is also important to avoid extreme shock or impact.

#### POWER SAVING MECHANISM

In order to extend the battery life of your watch when it's not in use, gently pull the stem/crown out until you feel it click. This will reduce battery power consumption by 70%. Please note that this is the same stem/crown position that is used to perform a quick TIME SETTING. If your watch features a screw-down crown, follow the instructions at the beginning of this manual to release the crown before pulling it out all the way.

#### END OF BATTERY LIFE (EOL)

Your quartz watch is equipped with a feature to indicate when the battery level is low. When the battery gets to that stage, the second hand will jump 4 steps at a time, every 4 seconds. This behavior lowers the power consumption while still displaying the time accurately and letting you know that it is time to change the battery.

### LIMITED LIFETIME WARRANTY

Your Filson watch is warranted by Shinola for the lifetime of the watch under the terms and conditions of this warranty. The Shinola warranty covers faulty workmanship under normal use for the lifetime of the product. In case of defects covered by the warranty, all components (excluding battery, leather strap and buckle) will be repaired or the watch will be replaced free of charge. In the case of a replacement, Shinola cannot guarantee that you will receive the same watch model. If your model is not available a watch of equal value and similar style will be provided. A copy of the receipt and/or your completed Certificate of Warranty is required as proof of purchase. A check or money order payable to Shinola/Detroit, LLC in the amount of \$25.00 as service and handling fee must be included for all warranty and repair services. The fee is subject to change.

#### THIS WARRANTY DOES NOT COVER

- Leather, rubber or nylon strap, battery or buckle.
- Damage resulting from improper handling, lack of care, accidents or normal wear and tear.
- Water damage unless marked water-resistant.
- This warranty is void if the watch has been damaged by accident, negligence of persons other than authorized Shinola sales or services agents, unauthorized service, or other factors not due to defects in materials or workmanship.
- If you have your watch battery replaced by any service provider other than a Shinola authorized service center, such replacement will not void your warranty, so long as such replacement (i) is performed by an experienced and legitimate service center, (ii) is not performed in a negligent manner, and (iii) is reassembled properly, including without limitation, replacement of gasket if necessary to achieve suitable water-tightness. Shinola has the right to determine, in its sole and absolute discretion, if any such third party battery replacement voids your warranty.
- The following warranties and remedies are exclusive and in lieu of all other warranties, terms or conditions, express, implied or statutory, as to any matter whatsoever, including, without limitation, warranties of merchantability, fitness for a particular purpose, accuracy, satisfactory quality, title, and non-infringement, all of which are expressly disclaimed by Shinola. Shinola shall not be liable for incidental, consequential, indirect, special or punitive damages or liabilities of any kind arising out of or in connection with the sale or use of this product, whether based in contract, tort (including negligence), strict product liability or any other theory, even if Shinola has been advised of the possibility of such damages and even if any limited remedy specified herein is deemed to have failed of its essential purpose. Shinola's entire liability shall be limited to replacement or repair at Shinola's sole option. However some countries, states, or provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental consequential damages so the above exclusions and limitations may be limited in their application to you. When implied warranties may not be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights; you may have other rights that may vary depending on local law. Your statutory rights are not affected.

#### REQUESTING WARRANTY AND OTHER WATCH REPAIR

Should you require work under warranty, please send in your watch, a copy of your sales receipt and a completed watch repair form, which can be found on the Filson website ([www.filson.com](http://www.filson.com)), to the authorized international watch service center listed below. Do not send original packaging, as it will not be returned. Shinola highly recommends you insure your parcel and adequately protect the watch during shipment. Shinola is not responsible for product lost or damaged during shipment.

For service work that is not covered under this warranty, the service center may perform the services you request for a charge dependent on watch style and type of work requested. Such charges will be notified and agreed by you prior to performing the services.

In addition to repair charges, if required, a service and handling fee of \$25.00 will be charged for all repairs and warranty services. Such fee must be prepaid by check or money order payable to Shinola/Detroit, LLC at the time of delivery of the watch to the repair center. This fee is subject to change.